


**The No. 1
Bird Deterrent**

Australian Owned & Operated




To be effective, the BIRD BUSTA bird deterrent must be fitted in an area that has at least a slight breeze and must be fitted horizontal to the ground and not on an angle.

INSTRUCTIONS:

- Step 1:** Loosen clamp screw ④ anti-clockwise half a turn.
- Step 2:** Extend arms ② to required or maximum length (arms should be equi-distant).
- Step 3:** Twist arms ② so that flaps ① are in upright vertical position.
- Step 4:** Tighten clamp screw ④ clockwise (firmly).
- Step 5:** Use holes in base ⑨ to secure by screws or clamp (not included).

EXTRA FEATURES: Retainer clip ⑥ reduces the possibility of the upper bearing ⑤ separating from the lower bearing ⑧ in strong winds, clip ⑥ must be in position before unit is operating. Should you need to stop the unit, simply remove clip ⑥ and insert into stop hole ⑦, be sure to return retainer clip ⑥ to original position before operating. To remove the entire assembly from the base ⑨ simply turn the lower bearing ⑧ clockwise (a quarter turn) and pull out. To replace, push the lower bearing ⑧ back in position and twist anti-clockwise until it locks into place, this feature is available on bayonet base model only. For application on a structure taller than a single storey home or for commercial use, it is recommended to use the BIRD BUSTA solid base series.



WARNING: This device is NOT a toy and is unsuitable for children. Due to the various applications for the BIRD BUSTA, fittings, brackets or clamps, etc are not supplied. Bird Busta (Aust) suggests that a suitable fitting, bracket or clamp etc be used to mount this device in an area that is unlikely to cause damage to property or injury to a person and should be fitted/mounted by a person with the required skills to do so.